

Process Control as Inventory Control

R. Russell Rhinehart

Develop Your Potential Series in CONTROL magazine, Vol. 31, No. 6, June 2018, pp 42.

Often, chemical process control is fundamentally inventory control. Understanding the cause-and-effect of the inventory is key to understanding the process, to trouble shooting, choosing appropriate CV-MV pairing, designing cascade or ratio structures, specifying safety overrides, and developing models (either first-principles or empirical).

Usually, we don't measure the inventory. We measure the response to it. Unfortunately, an initial focus on the response often distracts the person from seeing the fundamentals. Recognize the fundamental mechanism. Here are several examples:

Inventory of gas molecules results in pressure. A standard air compressor can be an example.




Figure 1: Air Compressor

The inventory relation of number of molecules to the response can be revealed by the ideal gas law, $PV = nRT$, which leads to $P = \frac{nRT}{V}$. When you release gas or add gas, you are changing the inventory of molecules, and pressure is a response. Note: Pressure does not flow in or out. Gas molecules are what move, and pressure is the response.

Inventory of liquid material results in volume, level, or weight. Figure 2 illustrates flow into and out of a right cylindrical tank.




Figure 2 – Liquid flow into and out of a tank

Again, the relations are simple. Volume is the product of height and area, and volume times density is mass. $V = hA$, $V\rho = m$. So, the response, level, is dependent on the inventory of material. $h = \frac{m}{A\rho}$.

To change level, you add or release material. Note: Level does not flow in or flow out, but level changes. Material in- and out-flow causes the inventory to change. Level is just a measure of inventory.

The situation is similar for solid accumulation. Figure 3 is an integrating process of filling a transport volume.




Figure 3: Solids Feeder

The weight is the mass flow rate times the duration: $W = \dot{m} \Delta t$. Or, more properly, with gravity and dimensional units considered $W = m \frac{g}{g_c} = \dot{m} \Delta t \frac{g}{g_c}$.

Inventory of two materials results in composition, as Figure 4 illustrates by blending liquids in a tank.




Figure 4: Blending Liquids

Here, x represents the mass fraction of component A. $x_A = \frac{m_A}{m_A + m_B}$. Whether the composition is measured by volume fraction, mole fraction, normality, concentration, or pH, the measurement is a response of the inventory of A and B which is related to the inflow of each and the joint outflow.

Inventory of thermal energy (heat) results in temperature, as Figure 5 illustrates.




Figure 5: Heating an Object

The relation between heat added and temperature rise is $mC_p\Delta T = Q$, where $\Delta T = T_{after} - T_{before}$ heat is added. Then $T = T_0 + \frac{Q}{mC_p}$. Again, the controller does not add temperature, it manages processes that add or remove thermal energy, and temperature is the response. It does not matter whether the heater is a flame, or an electrical element, or a chemical or nuclear reaction. It does not matter whether the object is solid, liquid, or gas. The analysis is similar. If you want to increase temperature, you do not add temperatures, you add heat. Temperature is the response.

Process control is control of the rates that inventory changes, with the purpose to manage the rates that P, T, V, h, W, X change. First, look for the inventory, then its response, and choose procedures to control the inventory.

Of course, there are exceptions. In flow rate we manipulate valve position to increase or decrease flow rate. Here, I don't see the inventory concept that results in flow rate. So, when we are introduced to control with flow rate examples, it might lead one to miss the inventory concept in most applications.